ECONTROL COMFORT 230/II

Pump Control Panel for Dual Pump Operation

Power Supply: 1x230V, N, PE

Nominal Current: up to 1x16A see Panel Details

Duty Cycle: 100%

Dimensions: 318x267x167mm

Protection: IP 63

Protection Category: class II equipment

Alarm Exit: Potential-free output, max. 250V/5A

Alarm Exit II: Output 230V, 50Hz, 2A



1. Specifications

Electric Pump Control Panel for 2x single-phase and capacitor integrated submersible pumps up to 2.2kW each. Automatic operation is enabled via external Float-Switch/Pressure-Switch. Protection degree of the Panel is IP 63.

The Panel is equipped with a lockable red-yellow Main Switch, Manual ("Hand") – OFF ("AUS") – Automatic ("Automatik") Switch for each pump, protective overload motor-switch (2x) with alarm indication, 2x LEDs for each pump displaying Operation ("Betrieb"/green) and Alarm ("Störung"/red).

There are 4x Panel Inputs for *Automatic Operation* (float-switch/pressure-switch), *Peak Load* (float-switch/pressure-switch), *High Level Alarm* (float-switch) and *Dry-Run Protection* (float-switch). Furthermore the Panel has a potential-free general fault/alarm output and an alarm output for acoustic and optical external devices with 230V/50Hz, max. 2A.

2. Operational Description

For automatic operation ("Betrieb") one of the pumps is switched via the external device (float-switch/pressure-switch) for normal operation. After every pump cycle the pump is changed to obtain equal operational hours. The operating mode is displayed by the green LED.


During *Peak Load* ("Spitzenlast") the external device for peak operation (float-switch/pressure-switch) switches the non-operating pump on as backup. The pumps will be switched as normal after the cycle has ended.


The (optional) external device for *High Level Alarm* ("Störung") signals high water level inside the pump chamber or storage tank. This is displayed via the red LED, the potential-free general fault/alarm output and the alarm output for external devices (e.g. buzzer). *High level Alarm* does not interrupt automatic pump operation.


Current overload (protective overload motor-switch) is displayed separately via the red LED of each pump and the potential-free general fault/alarm output only. Automatic pump operation is limited to the remaining operational pump. In order switch on again the protective overload motor-switch for each pump, it is necessary to open the Panel.


The external device (e.g. float-switch) for *Dry-Run Protection* interrupts automatic pump operation. Manual operation of the pumps is then still possible. At factory setting the contacts for the external device are bridged. Automatic operation is possible without *Dry-Run Protection*. It is however <u>strongly recommended</u> to connect an external device providing *Dry-Run Protection*.











Zustand #				Kabelbezeichnung extern							Klemmleist	F	Kabelbezeichnung intern										
Anderung Datum Name											Funktionstext	ziel z Bezeichnung	extern Anschluß	Klemmennummer	Brücken	•	Ziel inter: Anscritus Bezeichnung				5		Blatt/Pfad
Norm	Gepr.	Bearb.	Datum			Po	wer	Su	pp1	У	Einspeisung			1 2				1 5					2.1
H		-	30					Pu	mn	1	PE Pumpe 1	-M1	E1	PE 3	-		-K2	2					2.1
			08.01.08					Fu	III D	±	Tumpo I	-M1	E2	4				6					2.3
			80				ii.	Pu	щр	2	Pumpe 2	-M2	E1	PE 5	!		-K3	2	-				2.3
Urspr.			,									-M2	E2	6 PE			-к3	6					2.4
pr.	Comfort	ECONTROL					О	per	ati	on	Betrieb	-B1	???	7	•		-F1 E	2					3.1
	lfor	ž					D	ry-	Run		Trockenlauf	-B1 -B2	???	8 9				-	-				3.1
	-	RO				3,25,5						-B2	???	10			-K1 A	L			7.		3.1
Ers.		L 2												PE PE	i								3.1
s. f.		230/2		\vdash			P	eak	<u>-Lo</u>	ad	Spitzenl.	-B3	333	11 12	H	-		2					3.2
		10									71	- P1		PE	•								3.2
											Alarmsignal	-P1 -P1	2	13 14			-K6 A						4.4
Ers.					Hig	h I	eve	1 A	lar	m	Störung	-B4	7?? ???	15 16	•		-F1 E	3		- 1			4.4
a.																							1.1
											2.577								-		- 3		
													v										
6		П																					
31	Ď	EBAKA Pumps Europe	Ö					18			100 c (- 		100					+		-			
28	pp	7]																	2017 - TAIL			
Die	Philipp-Reis-Straße 15		7												E)	1				221			landy.
zei	Sis	mp																					
nba	Str	SI II									5.000 B												
ch	Sa Sa	uro				31. 4					81	1 - 11 - 11				-						-	
	<u>а</u>	90									**												
-	<u>5</u>		1																				
											***					-				HIII			-
																1							
											6.5		334 :										
																-							
																+		+	\vdash		_		
	-		4																			- 1	
															<u> </u>								
von 6	Blatt																						
	tt 5						1									\exists							
B1.																						[

2	_	_	_		-																	
Zustand Änderung							bezei exter		I		Klemmleist	e:-X2	0				K	abell i	beze Lnte:		ing	Seite 2
nderung Datum Name								Ŷſ.			Funktionstext	Ziel exter	C Brackling	Klemmennummer	Brücken	Niel intern Anschluß Bezeichnung	5	8		=		Blatt/Pfad
	Gepr.	Bearb.	Datu			Gen	era	1 F	aul	t .	Sammelstörm, pot		21	1								4.5
		\dashv	1155		12								24 22	3								4.5
			08.01.08																			
Urspr.	Comfort											10000								2		
	fort	ECON ROL	NTDO																			
Ers. f.		L 230/2	300																			
		N	3											10.00								
Ers.																						
d.						*****				4-10-10-10-10-10-10-10-10-10-10-10-10-10-												
63	Ph	<u>п</u>																				
128 D	Philipp-Reis-Straße 15	EBARA Pumps Europe																				
63128 Dietzenbach	Reis-S	umps																				
bach	Straße	Europ							. = 855				1									
	15	. 0																				
													1									
										1.00			1					At-				
						=		-														
			\dashv	12																		
- 4	Blatt 6																	8				
B1.]											CVC AN			