

Bacteria measurement in waterless and waterflushed urinals

Results of a study of the Landesgewerbeanstalt Bayern LGA from 2nd Oktober 1997

Type of Urinal Test	Findings [CFU* / 100 cm ²]	found microorganism
Waterflushed Urinal Inside before flushing	114.42	Bacteria, Moulds
Waterflushed Urinal Edge before flushing	216	Bacteria, Moulds
Waterflushed Urinal Inside after flushing	360.54	Bacteria, Moulds
Waterurinal Edge after flushing	168	Bacteria, Moulds
Push Button	276	Bacteria, Moulds
Urin	0	-
Waterless Urinal uncelaned	0.6	Bacteria
Waterless Urinal 2 uncleaned	18	Bacteria
Waterless Urinal 3 uncleaned	42.3	Bacteria
Waterless Urinal 4 uncleaned	6	Bacteria

* Colony forming unit